

CARBON FIBER MIRROR CAPS – ABARTH 500 – FT500-01



1. Add adhesive behind the CF part or onto the socket of mirror cap (we recommend to use black bodywork glue or any strong structural adhesive).



2. On the bottom side of the CF mirror cap, It's a clasp where it must go in the socket as seen in step 3.



3. This is the socket, where the clasp goes.



4. After you've added adhesive to the Mirror socket, first push the edge carefully toward socket.



5. Then push the bottom part (where the clasp is) to clamp the CF part with socket.



6. Fix it with some tape, on top side and bottom side, to hold the position you've glued as seen in picture below.



7. Wait at least for 12-24 hours, glue to get hardened.