

INSTRUCTION

Alfa Romeo Giulietta / Mito Mirror Caps [ARG-005]

1.This product is replacement so you need to remove the OEM part.



2.Before you add some adhesive clean a little bit the behind of carbon fiber part with sand paper.



3.After that add adhesive to the points as is shown in the photo (We recommended Black Bodywork Silicon Glue as adhesive such as 3M or Wurth).

4.Mount the product in the right position and keep the position until adhesive is dry.