

# INSTRUCTION

## Fiat 124 Abarth Mirror Caps [ FT124-01 ]

1.This product is a replacement, you need to remove OEM mirror caps first.



2.Before you add some adhesive clean a little bit the behind of carbon fiber part with sand paper.

3.After that add adhesive at the lines as is shown in the photo (We recommended Black Bodywork Silicon Glue as adhesive such as 3M or Wurth).



do the same both sides

4.Mount the product in the right position and keep the position until adhesive is dry.